

Space Bar SB-1312 for PT-100-1312/PT-100-1312-DP. **At new installation**, put SB-1312 in the same middle slot as tray at the same moment. Gives extra stability.



SB-1312 for PT-100-1312/PT-100-1312-DP trays. **After existing installation**, slightly lift upper tray and install SB-1312 in square hole above tray. Gives extra stability.